

## **General Disclaimer**

### **One or more of the Following Statements may affect this Document**

- This document has been reproduced from the best copy furnished by the organizational source. It is being released in the interest of making available as much information as possible.
- This document may contain data, which exceeds the sheet parameters. It was furnished in this condition by the organizational source and is the best copy available.
- This document may contain tone-on-tone or color graphs, charts and/or pictures, which have been reproduced in black and white.
- This document is paginated as submitted by the original source.
- Portions of this document are not fully legible due to the historical nature of some of the material. However, it is the best reproduction available from the original submission.

**NASA TECHNICAL  
MEMORANDUM**

**NASA TM X- 73941**

**NASA TM X- 73941**

Particle Size and X-Ray Analysis of  
Feldspar, Calvert, Ball, and Jordan Soils

By

Raymond S. Chapman

(NASA-TM-X-73941) PARTICLE SIZE AND X-RAY  
ANALYSIS OF FELDSPAR, CALVERT, BALL, AND  
JORDAN SOILS (NASA) 24 p HC A02/MF A01

N77-16481

CSCI 08M

Unclass

G3/46 13257

February 1977

This informal documentation medium is used to provide accelerated or special release of technical information to selected users. The contents may not meet NASA formal editing and publication standards, may be revised, or may be incorporated in another publication.

**NATIONAL AERONAUTICS AND SPACE ADMINISTRATION  
LANGLEY RESEARCH CENTER, HAMPTON, VIRGINIA 23665**



1. Report No. NASA CR-73941		2. Government Accession No.		3. Recipient's Catalog No.	
4. Title and Subtitle Particle Size and X-Ray Analysis of Feldspar, Calvert, Ball, and Jordan Soils				5. Report Date February 1977	
				6. Performing Organization Code 6530	
7. Author(s) Raymond S. Chapman				8. Performing Organization Report No.	
				10. Work Unit No. 177-55-31-02	
9. Performing Organization Name and Address NASA Langley Research Center Hampton, VA 23665				11. Contract or Grant No.	
				13. Type of Report and Period Covered Technical Memorandum	
12. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington, D.C. 20546				14. Sponsoring Agency Code	
15. Supplementary Notes					
16. Abstract  <p>Pipette analysis and X-ray diffraction techniques are employed to characterize the particle size distribution and clay mineral content of the Feldspar, Calvert, Ball, and Jordan soils. In general, the Ball, Calvert, and Jordan soils are primarily clay size particles composed of Kaolinite and Illite whereas the Feldspar soil is primarily silt-size particles composed of Quartz and Feldspar minerals.</p>					
17. Key Words (Suggested by Author(s)) Environment Pollution, Feldspar, Calvert, Ball, and Jordan soils			18. Distribution Statement Unclassified - unlimited		
19. Security Classif. (of this report) Unclassified	20. Security Classif. (of this page) Unclassified	21. No. of Pages 22	22. Price* \$3.50		

PARTICLE SIZE AND X-RAY ANALYSIS OF FELDSPAR,  
CALVERT, BALL, AND JORDAN SOILS

Raymond S. Chapman\*

Langley Research Center

SUMMARY

By using pipette analysis and X-ray diffraction techniques, the particle size distribution and clay mineral content of the Feldspar, Calvert, Ball, and Jordan soils are investigated. The results show the Ball, Calvert, and Jordan soils are primarily clay-size particles composed of Kaolinite and Illite. The Feldspar soil, however, is primarily silt-size particles composed of Quartz and Feldspar minerals.

INTRODUCTION

Interest in environmental monitoring has led to research involving the remote sensing of suspended sediments in rivers, estuaries, and the oceans. Currently, studies are underway to define the potential of remote sensing for identifying and monitoring Feldspar, Calvert, Ball, and Jordan clay types of sediments. It is the purpose of this report to characterize the particle size distribution and clay mineral content of the Feldspar, Calvert, Ball, and Jordan soils using pipette analysis and X-ray diffraction techniques, respectively. These basic data are required to support both experimental and optical modeling studies being conducted at several research organizations.

PARTICLE SIZE ANALYSIS

Of the various methods used in particle size analysis of the less than 62 $\mu$  fraction, pipette analysis is considered the simplest and most reliable. The technique of pipette analysis, which is based on the particle settling velocity as related to its diameter by Stocks law, is described in detail by Folk (ref. 1). By applying this technique to a sample of each of the four soils, cumulative size distributions were obtained as shown in figures 1-4.

By adopting the American Society for Testing Materials standard for particle size fractions, (table 1) the soils can be characterized by their percent sand, silt, and clay size material (ref. 2).

\*Mr. Chapman is an Old Dominion University graduate student working for LaRC as a Graduate Engineering Resident participating in Engineering.

Table 1. Particle Size Fractions

(ASTM, 1964)

Particle Size Fraction	Particle Size (mm)
Sand	0.074 - 4.76
Silt	0.005 - 0.074
Clay	<0.005

Referring to figures -4, the soils are characterized as follows:

Feldspar	< 2% Sand
	76% Silt
	22% Clay
Calvert	2% Sand
	18% Silt
	80% Clay
Ball	< 2% Sand
	12% Silt
	86% Clay
Jordan	4% Sand
	23% Silt
	73% Clay

## CLAY X-RAY ANALYSIS

The general concept of X-ray diffraction analysis is covered well by Kuo and Cheng (ref. 3), however, the criteria for identification of clay minerals have been adopted from Schultz (ref. 4) and Carrol (ref. 5). In applying these criteria, the subsequent analysis is restricted to the specific clay minerals Kaolinite, Illite, Chlorite, and Montmorillonite due to their abundance and importance; and to a general classification, namely, mixed-layered clays.

(NOTE: Criteria for identification should come before preparation and treatment of samples.)

### CRITERIA FOR IDENTIFICATION

Kaolinite exhibits a first-order peak at  $7\text{A}^\circ$  which when heat-treated at  $550^\circ\text{C}$  diminishes or collapses entirely.

Illite exhibits a first-order peak at  $10\text{A}^\circ$ .

Chlorite exhibits a first-order peak at  $14\text{A}^\circ$  which will often expand when heat-treated at  $550^\circ\text{C}$ .

Montmorillonite is characterized as having little response in the untreated state, however, it exhibits a  $17\text{A}^\circ$  peak when treated with ethylene glycol. When heat-treated at  $180^\circ\text{C}$ , the  $17\text{A}^\circ$  peak shifts to  $9.8\text{A}^\circ$  due to the volatilization of the ethylene glycol and absorbed water.

Mixed-layered clays are characterized as being interstratification of various clay minerals which exhibit broad peaks in the  $10\text{A}^\circ$  to  $17\text{A}^\circ$  range.

### PREPARATION AND TREATMENT OF SAMPLES

Using the less than  $2\mu$  fraction from the particle size analysis, a slide mount of each soil was made using a smear technique. After drying at room temperature, the following treatments were applied in succession:

1. No treatment
2. Ethylene Glycol treatment
3.  $180^\circ\text{C}$  treatment
4.  $550^\circ\text{C}$  treatment

## INTERPRETATION OF RESULTS

### Feldspar

All four treatments indicated the presence of Montmorillonite, Chlorite, or mixed-layered clays in trace amounts. No significant differences in the four diffraction patterns were noted; thus, a single diffraction pattern than of the unheated sample is presented. However, under optical examination the vast majority of the samples were found to be Feldspar and Quartz, which conforms with the occurrence of the  $6.4\text{\AA}$  Feldspar peak (fig. 5).

### Calvert

The untreated sample exhibited distinct  $10\text{\AA}$  and  $7\text{\AA}$  peaks (fig. 6). No significant change occurred with either the ethylene glycol  $180^\circ\text{C}$  treatments (fig. 7 and 8). With the  $550^\circ\text{C}$  treatment, the  $7\text{\AA}$  peak collapsed (fig. 9). Thus, the primary clay minerals are Kaolinite and Illite.

### Ball

The untreated sample exhibited  $17\text{\AA}$ ,  $10\text{\AA}$ , and  $7\text{\AA}$  peaks (fig. 10). With the ethylene glycol treatment, the  $17\text{\AA}$  peak became more prominent which indicates the presence of Montmorillonite (fig. 11). With  $180^\circ\text{C}$  treatment, the  $17\text{\AA}$  peak apparently shifted to  $9.8\text{\AA}$  which also indicates the presence of Montmorillonite (fig. 12). When treated at  $550^\circ\text{C}$ , the  $7\text{\AA}$  peak collapsed which insures the presence of Kaolinite. No apparent increase in the  $14\text{\AA}$  occurred with the  $550^\circ\text{C}$  treatment, hence, the likelihood of Chlorite is small (fig. 13). Thus, the constituent clay minerals are Kaolinite, Illite, Montmorillonite, and some mixed-layered clays.

### Jordan

The untreated sample exhibited strong  $7\text{\AA}$  and  $10\text{\AA}$  peaks, with weak  $14\text{\AA}$  and  $17\text{\AA}$  peaks (fig. 14). The ethylene glycol treated sample exhibited no expansion of the  $17\text{\AA}$  peak, hence, the likelihood of Montmorillonite is small (fig. 15). Similar results were obtained in the  $180^\circ\text{C}$  treatment (fig. 16); however, the collapse of the  $7\text{\AA}$  peak with the  $550^\circ\text{C}$  treatment indicates the presence of Kaolinite (fig. 17). Thus, the primary clay minerals are Kaolinite, Illite, and some mixed-layered clays.

## CONCLUDING REMARKS

Utilizing pipette analysis and X-ray diffraction techniques, the particle size distribution and clay mineral content of the Feldspar, Calvert, Ball, and Jordan soils have been investigated. All soils have a low percentage of sand, and Feldspar has a high percentage of silt. The Ball, Jordan, and Calvert soils have a high percentage of clay size particles. Considering mineral content, the Feldspar soil is composed primarily of Feldspar and

Quartz minerals. Primary clay minerals in both the Calvert and Jordan soils are Kaolinite and Illite; however, the Jordan soil has some mixed-layered clays. The Ball soil is composed primarily of Montmorilloite, Kaolinite, Illite, and some mixed-layered clays. The results herein are a basic characterization and by no means completely describe the soils investigated.

#### REFERENCES

1. Folk, R. L.: Petrology of Sedimentary Rocks. Hemphill Publishing Co., 1974.
2. Jumikis, A. R.: Introduction to Soil Mechanics. D. Van Nostrand Co. Inc., 1967.
3. Kuo, C. Y. and Cheng, R. Y. K.: Laboratory Requirements for In Situ and Remote Sensing of Suspended Materials. O.D.U. School of Engineering Technical Report 76-C2, Norfolk, Virginia, 1976.
4. Schultz, L. C.: Quantitative Interpretation of Mineralogical Composition from X-Ray and Chemical Data for the Pierce Shale. USGS Prof. Paper 391-C, 1974.
5. Carrol, D.: Clay Mineralogy: A Guide to Their X-Ray Identification. GSA Special Paper 129, 1970.






Figure 1.- Cumulative size distribution of Feldspar sample.




Figure 2.- Cumulative size distribution of Calvert sample.




Figure 3.- Cumulative size distribution of Ball sample.




Figure 4.- Cumulative size distribution of Jordan sample.




Figure 5.- X-ray diffraction pattern of untreated Feldspar Clay.






Figure 6.- X-ray diffraction pattern of untreated Calvert Clay.




Figure 7.- X-ray diffraction pattern of ethylene glycol treated Calvert Clay.




Figure 8.- X-ray diffraction pattern of 180°C treated Calvert Clay.






Figure 9.- X-ray diffraction pattern of 550°C treated Calvert Clay.




Figure 10.- X-ray diffraction pattern of untreated Ball Clay.




Figure 11.- X-ray diffraction pattern of ethylene glycol treated Ball Clay.




Figure 12.- X-ray diffraction pattern of 180°C treated Ball Clay.






Figure 13.- X-ray diffraction pattern of 550°C treated Ball Clay.




Figure 14.- X-ray diffraction pattern of untreated Jordan Clay.




Figure 15.- X-ray diffraction of ethylene glycol treated Jordan Clay.




Figure 16.- X-ray diffraction pattern of 180°C treated Jordan Clay.






Figure 17.- X-ray diffraction pattern of 550°C treated Jordan Clay.